






Инструкция по сборке типовая
ТВ-тумба Вест 180х50
180х40х50

Сборка согласно
заказанной комплектации:









№	Размер деталей	Количество
1	1800*400*16	1
2	1800*400*16	1
3	396*120*368	1
4	396*120*368	1
5	368*350*16	2
6	368*379*16	1

№	Размер деталей	Количество
7	380*350*16	2
8	369*350*16	2
9	781*378*5	2
10A/B	362*387*16	3
11	362*387*16	1
12	1600*348*95	1




Фурнитура




M6*40

A=24



Φ 8*30

B=40




Φ 15*12

C=24




Φ 21


D=24



E=12




F=1



Φ 7*50

Q=10




I2=4




M4


H=1



I3=4



K=4




L=16




M3.5*12

V1=8


Шаг 1




Шаг 2




Шаг 3




Шаг 4




Шаг 5




Шаг 6




Шаг 7




Шаг 8







Шаг 9




Шаг 10




Шаг 11



Шаг 12



Шаг 13



Шаг 14

